

Riga

Cleaning and Stacking Care and Instructions

Normal Cleaning

Dust furniture with a slightly damp soft lint-free cloth or a proprietary domestic furniture polish. Do not use abrasive cleaners. Wipe dry with a dry soft cloth in the direction of the wood grain.

NOTE:

1. Do not allow hot articles to come into contact with the surface, as damage will occur.
2. Small spills should be removed immediately using a damp cloth.

Once a Month

Clean the surface with a soft cloth dampened with a quality cleaner formulated for wood furniture. Wipe the surface in the direction of the wood grain to remove dirt and fingerprints. Wipe dry with a clean dry cloth.

Twice a Year

Apply a good quality furniture polish with a clean soft cloth. Do not use aerosol-powered cleaners or polishes. Also, do not use polishes containing waxes or abrasives, or polishes that are oil based.

Minor Repair of Water Rings, Stains, and Scratches

Rub the surface lightly in the direction of the wood grain using No. 000 steel wool. Apply a scratch-removing polish with a color and value that simulates the veneer. If the scratches are deep, consult a professional furniture refinisher

Stacking Chairs

The Riga chair can be stacked 15 chairs high. Do not exceed this amount.

To prevent premature wear on the leg surfaces, place each chair on top of one another without dropping or moving the chairs side to side. Be mindful that these are natural wood chairs that can be dented or scratched. Care should be taken when stacking or unstacking these chairs.

-Keep chairs free of dust and dirt along the surfaces where the chair legs touch.

